B. Haidar

Structural Mechanics (2)

Lecture No-01

Analysis of Indeterminate Structures - Force Method

- Indeterminate Structures vs. Determinate Structures
- Analysis of Indeterminate Structures.
- Structures with single Degree of Indeterminacy (Beams & Frames)
- Structures with single Degree of Indeterminacy (Trusses: Int. & Ext.)

STRUCTURES

are classified from the analysis point of view to

DETERMINATE

INDETERMINATE

To predict the performance of a structure, its response elements such like sup. reactions, internal forces, stresses, deflections, strain, to external actions Loads, sup. settlement, temp. changes & fabric. errors, must be determined.

Response elements are separable to	Response elements are not separable
Forces: support reactions & internal forces, then stresses, are determined by equilibrium equations	support reactions & internal forces number is greater than the available equilibrium equations
Deformations: deflections & Strains, are determined after knowing the first group	additional relationships based on the geometry of deformation of structures, are needed

INDETERMINATE STRUCTURES

Advantages	Disadvantages
greater overall factor of safety	more sensitive to secondary effects
1. Smaller Stresses 2. Greater Stiffness 3. Redundancies	1. Fabrication errors 2. Temperature changes 3. Support settlements

Statically Indeterminate Structures - Disadvantages



Statically Determinate



Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

1. Fabrication errors:



Statically Determinate



Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

1. Fabrication errors:



If this is accidentally
Fabricated too long…
All joints just move to
New positions



Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

1. Fabrication errors:



If this is accidentally
Fabricated too long…



Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

1. Fabrication errors:



If this is accidentally
Fabricated too long…
Then it must be
Compressed into place



Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

1. Fabrication errors:



Statically Determinate

If this is accidentally
Fabricated too long…
Then it must be
Compressed into place

Which puts these in tension



Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

1. Fabrication errors:

Which puts forces on all members



If this is accidentally
Fabricated too long…
Then it must be
Compressed into place



Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

1. Fabrication errors:



No Stresses. Members go together.

Statically Determinate



Members must be forced to fit.

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

2. Temperature Changes:



Statically Determinate



Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

2. Temperature Changes:





No Stresses. Positions just change

Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

2. Temperature Changes:



No Stresses. Positions just change

Statically Determinate

Joints restricted by truss-action



Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

2. Temperature Changes:



No Stresses. Positions just change

Statically Determinate



Thermal causes stresses

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

B. Haidar

2.

d

e



Thermal causes stresses

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

B. Haidar

2.

d

e



Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses



Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

3. Foundation Settlement:



Any Settlement: No Curvature. No moment

Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

3. Foundation Settlement:



Any Settlement: : No Curvature. No moment

Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

3. Foundation Settlement:



Any Settlement: : No Curvature. No moment

Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

3. Foundation Settlement:



Any Settlement: : No Curvature. No moment

Statically Determinate



Statically Indeterminate

Statically Indeterminate Structures - Disadvantages

Geometric changes cause indirect stresses

3. Foundation Settlement:



Any Settlement: : No Curvature. No moment

Statically Determinate



Any Settlement: : Curvature! Moment!

Statically Indeterminate

Statically Indeterminate Structures - Advantages



Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Advantages





Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Advantages

1. Lower Stresses:





Statically Determinate



Statically Indeterminate

Statically Indeterminate Structures - Advantages

B. Haidar

2. Greater Stiffness:



Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Advantages

2. Greater Stiffness:



Statically Determinate

Statically Indeterminate

Statically Indeterminate Structures - Advantages



A catastrophic event eliminates the middle pier

Statically Determinate: $DOI_s = 0$

Statically Indeterminate: $DOI_s = 1$

Statically Indeterminate Structures - Advantages

2. Greater Robustness: – May survive redundant loss of massive overload



Will NOT Survive
(zero redundancy)

MAY Survive
(if the beam can take a
Substantial increase in moment)

A catastrophic event eliminates the middle pier

Statically Determinate: $DOI_s = 0$

Statically Indeterminate: $DOI_s = 1$

ANALYSIS OF INDETERMINATE STRUCTURES

Three Pillars of Mechanics

Equilibrium Equations	Constitutive Equations or Behavior Lows	Compatibility Equations

the response elements
(support reactions, internal forces, stresses, deflections, strain)
are classified into primary & secondary unknowns

Force methods

Primary unknowns are reactions & Internal forces
Secondary unknowns are displacements: deflections & rotations (slopes)

Displacement methods

Primary unknowns are displacements: deflections & rotations (slopes)
Secondary unknowns are reactions & Internal forces

Force method: Beam with a single Degree of Indeterminacy

illustrative example



(a) Indeterminate Beam



(b) Primary Beam Subjected to External Loading and Redundant C_y

B. Haidar

Force method: Beam with a single Degree of Indeterminacy

Compatibility Equation

$$\Delta_C = \Delta_{CO} + f_{CC} C_y = 0$$



Bending Moment Diagram for Primary Beam Due to External Loading (kN-m)

+



Bending Moment Diagram for Primary Beam Due to Unit Value of C_y (kN-m/kN



=



(c) Primary Beam Subjected to External Loading

+



(d) Primary Beam Loaded with Redundant C_y

Force method: Beam with a single Degree of Indeterminacy

Compatibility Equation



$$C_y = -\Delta_{CO} / f_{CC} = 5P/16 = 50 \text{ kN}$$



(e) Support Reactions for Indeterminate Beam

By the method of section & using the equilibrium equations, the BM & SF diagrams can be found

Force method: Beam with a single Degree of Indeterminacy

Or, the BM diagram can be found using the superposition principle as



Bending Moment Diagram for Primary Beam Due to External Loading (kN-m)

+



$\times C_y$

Bending Moment Diagram for Primary Beam Due to Unit Value of C_y (kN-m/kN)

=



(f) Bending Moment Diagram for Indeterminate Beam (kN-m)

Force method: Beam with a single Degree of Indeterminacy

Example-01: Compute the support then draw the BM & SF diagrams for the following beam.



(a) Indeterminate Beam

SOLUTION: The beam is statically indeterminate to degree one. Select B_y as the redundant. Draw the two determinate frames (S_0) & (S_1)

Force method: Beam with a single Degree of Indeterminacy

Example-01: Compute the support then draw the BM & SF diagrams for the following beam.



(b) Primary Beam Subjected to External Moment M

S_0



(c) Primary Beam Loaded with Redundant B_y

S_1

The compatibility equation is

$$\Delta_{0B} + B_y f_{BB} = 0$$

Force method: Beam with a single Degree of Indeterminacy

B. Haidar

Example-02: Compute the support then draw the BM & SF diagrams for the following beam.



(a) Indeterminate Beam

SOLUTION: The beam is statically indeterminate to degree one. Select M_A as the redundant. Draw the two determinate frames (S_0) & (S_1)

Force method: Beam with a single Degree of Indeterminacy

Example-02: Compute the support then draw the BM & SF diagrams for the following beam.

S_0



(b) Primary Beam Subjected to External Loading

+

S_1



× M_A

(c) Primary Beam Loaded with Redundant M_A